

CE


DD510H Vibration Sensor Specification

Version NO.: A/oo



①If the voltage is less than 2.3V, the buzzer will ring every 5s to remind the user to change the battery; @Magnet function: the vibration and low voltage are invalid if there is no magnet.







Vibration sensor programming under uni-directional mode

pairing/adding emitter status

Pairing sensor or additional sensor setting

Dial the switch to o and press the

setting button once The receiver is under the



Release button

①After pairing the motor with DD510H, when there is strong wind, the sensor will send the UP command to close the awning: @There is a levels of sensor sensitivity and the sensitivity gradually decrease from 1 to 9 level, when it's 0 level, there is no sensitivity; 3The vibration sensor will send the UP command to the motor to close the awning once the vibration of the sensor reach the setting sensitivity level, and within 30s, the sensor won't send UP command again if the vibration continued; @When the sensor under Pairing sensor or additional sensor status, press the UP button of the remote, the awning can be closed.



Check the indicator status of receiver, whether the sensor or the additional sensor has been paired

Send UP command

Dial the switch to 5 and hold the setting button



Release button

OK

Once the sensor vibrated and reach the sensitivity level, the sensor will send the UP command.

Send DOWN command

Dial the switch to 9 and hold the setting button





Once the sensor vibrated and reach the sensitivity level, the sensor will send the DOWN command.





Vibration sensor programming under bi-directional mode

Additional function

Pairing sensor or additional sensor setting

Dial the switch to o and press the









①After pairing the motor with DD510H, when there is strong wind, the sensor will send the UP command to close the awning; @There is 9 levels of sensor sensitivity and the sensitivity gradually decrease from 1 to 9 level, when it's 0 level, there is no sensitivity; 3The vibration sensor will send the UP command to the motor to close the awning once the vibration of the sensor reach the setting sensitivity level, and within 30s, the sensor won't send UP command again if the vibration continued: (4)When the sensor under Pairing sensor or additional sensor status, press the UP button of the remote, the awning can be closed.

If press the Up button of the remote, the awning is open, pls switch the direction of the motor

If press the DOWN button of the remote,

the awning is closed, pls switch the direction of the motor.



Check the indicator status of receiver, whether the sensor or the additional sensor has been paired

Send UP command

Dial the switch to 5 and hold the setting button



Release button

If press the Up button of the remote, the awning is open, pls switch the direction of the motor.

If press the DOWN button of the remote,

the awning is closed, pls switch the direction of the motor.

OK

Once the sensor vibrated and reach the sensitivity level, the sensor will send the UP command.

Send DOWN command

Dial the switch to 9 and hold the setting button





Once the sensor vibrated and reach the sensitivity level, the sensor will send the DOWN command.



Release button