

OCEAN



MOTORI TUBOLARI

П

TUBULAR MOTORS

GB

ROHRMOTOREN

D

MOTEURS TUBULAIRES

F

MOTORES TUBULARES


F





ELECTRICAL CONNECTIONS

- To prevent any danger or malfunction, the size of electrical control components connected to the motor must be compatible with the electrical features of the motor.
- Means for disconnection must be incorporated in the fixed wiring in accordance with the national installation standards.
- The selectors inverting the direction of rotation of the motor must be provided with mechanical interlocking.
- Invert the brown and the black conductor to change the direction of rotation.
- NEVER connect two or more motors to the same selector (parallel connection) If you couple two motors, use multi-poles selectors only.
- NEVER connect two or more selectors to the same motor.


- For outdoor use, provide the appliance with a supply cable with designation H05RN-F containing at least 2% of carbon.







HOW TO PREPARE THE MOTOR



3. Insert the motor fully in the rolling tube.


NB: If you use tubes with a round form, the driving pulley must be fixed to the tube, and the installation is to be paid by the person who installs the system. For other tube sections the fixing is optional but strongly recommended.

3

ADJUSTEMENT OF THE LIMIT SWITCHES

Ocean tubular motors are provided with a system of electromechanical limit switches that stop the feed when the awning or the rolling shutter get to the maximum opening or closing limits. To adjust these limits and adapt them to any need, simply screw or unscrew the two adjusting screws on the motor head. The limits of the limit switches are preset at about three turns of the roller.

- To decide which adjusting screw to fix, simply watch the direction of rotation of the stop ring nut: if the stop ring nut pulled by the roller goes in direction A, use the adjusting screw A to set the limit switch in that direction. If it goes to the opposite direction (B), use the adjusting screw B.
- 2. Start up the awning or the rolling shutter in the direction in which you wish to set the first limit switch. After a few turns the motor will stop on the preset stop.
- Screw the adjusting screw suited to the direction (see point 1.) in direction "+" till it gets to the chosen position.
- 4. Invert the engine sense of direction and set the second limit switch.



DECLARATION OF CONFORMITY



Hereby, Cherubini S.p.A. declares that the OCEAN motors are compliant to UE Directives: Directive 2006/42/EC on machinery.

Directive 2014/35/EU safety of electrical equipment LVD.

Directive 2014/30/EU on electromagnetic compatibility.

The full text of the EU declaration of conformity is available upon request at the following website: www.cherubini.it.

CHERUBINI S.p.A.

Via Adige 55 25081 Bedizzole [BS] - Italy Tel. +39 030 6872.039 | Fax +39 030 6872.040 info@cherubini.it | www.cherubini.it

CHERUBINI Iberia S.L.

Avda. Unión Europea 11-H Apdo. 283 - P. I. El Castillo 03630 Sax Alicante - Spain Tel. +34 (0) 966 967 504 | Fax +34 (0) 966 967 505 info@cherubini.es | www.cherubini.es

CHERUBINI France S.a.r.l.

ZI Du Mas Barbet 165 Impasse Ampère 30600 Vauvert - France Tél. +33 (0) 466 77 88 58 | Fax +33 (0) 466 77 92 32 info@cherubini.fr | www.cherubini.fr

CHERUBINI Deutschland GmbH

Siemensstrasse, 40 - 53121 Bonn - Deutschland Tel. +49 (0) 228 962 976 34 / 35 | Fax +49 (0) 228 962 976 36 info@cherubini-group.de | www.cherubini-group.de

